



C/230 **Mozart set**

230 ml / h: 68 mm / Ø 90 mm



source Ø 160 mm



- Imprint on the handle
- Imprint on the inside
- Imprint on the bottom inside
- Imprint on the bottom outside
- 50 x 13 mm

- 40 x 15 mm

- Ø 25 mm

- Ø 20 mm

*In the case of projects for transfer print running outside of the standard print area, please contact our sales department.


[How to prepare print material](#)

meaning


- Transfer Print
- Sensitive Touch
- Direct Print

C/230 **Mozart set**

240 ml / h: 58 mm / Ø 100 mm



source Ø 160 mm



- Imprint on the handle - 50 x 13 mm
- Imprint on the inside - 40 x 15 mm
- Imprint on the bottom inside - Ø 25 mm
- Imprint on the bottom outside - Ø 20 mm

*In the case of projects for transfer print running outside of the standard print area, please contact our sales department.

[How to prepare print material](#)

meaning

Transfer Print

Sensitive Touch

Direct Print